





| ITEM | DESCRIPTION | PART NO. | REQ'D |
|------|-----------------------|-----------|-------|
| 1. | Swivel Plate | 1167-2-2 | 1 |
| 2. | Mounting Bracket | 1167-7-1 | 2 |
| 3. | Rocker Shaft | 1167-7-4 | 1 |
| 4. | Collar, with Setscrew | 1167-7-7 | 1 |
| 5. | Grease Fitting | 1167-3-18 | 2 |
| 6. | Latch Handle | 1167-5-8 | 1 |
| 7. | Hinge Pin | 1167-5-7 | 1 |
| 8. | Cotter Pin | 1167-5-22 | 2 |
| 9. | Latch Pin with Chain | 1167-5-11 | 1 |
| 10. | Safety Pin | 1167-5-14 | 1 |
| 11. | Plunger Lever | 1167-5-4 | 1 |
| 12. | Plunger Lever Spring | 1167-5-18 | 1 |
| 13. | Stud | 1167-5-5 | 1 |
| 14. | Washer | 1167-5-23 | 1 |
| 15. | Nut | 1167-5-24 | 1 |
| 16. | Cotter Pin | 1167-5-25 | 1 |
| 17. | Grease Fitting, 45° | 1167-6-17 | 3 |
| 18. | Jaw Set | 1167-6-1 | 1 |
| 19. | Jaw Bracket | 1167-5-1 | 1 |
| 20. | Bushing | 1167-7-9 | 2 |
| 21. | NOT USED | | |
| 22. | Jaw Pin | 1167-6-23 | 2 |
| 23. | NOT USED | | |
| 24. | Plunger | 1167-6-14 | 1 |
| 25. | Plunger Shaft | 1167-6-6 | 1 |
| 26. | Plunger Spring | 1167-5-17 | 1 |
| 27. | Set Screw | 1167-6-16 | 1 |
| 28. | Stud | 1167-6-5 | 1 |
| 29. | Washer | 1167-6-4 | 2 |
| 30. | Nut | 1167-6-18 | 2 |
| 31. | Cotter Pin | 1167-6-19 | 2 |
| 32. | Latch | 1167-5-15 | 1 |
| 33. | Spring | 1167-5-19 | 1 |
| 34. | Stud | 1167-5-16 | 1 |